

---

## Table of Contents

.....	1
I. Setup some global Variables which will be needed later .....	1
II. Load the measurment data into an iddata object .....	2
III. Open the System Identification Toolbox and performe the identification .....	2
IV. Save the identified models .....	3
V. Compare the models .....	4

```
%
#####
% TUHH :: Institute for Control Systems :: Control Lab
%
#####
% Experiment CSTD2: Magnetic Levitation Plant
%
% Copyright Herbert Werner and Hamburg University of Technology, 2014
%
#####
% This file is to be completed by the student.
% The completed version is to be published using
%   publish('cstd2_ident.m','pdf')
% and submitted as a pdf-file at least one week prior to the scheduled
%   date
% for the experiment
%
% HINT 1:
% if you want to find out more about a certain command, just type
% 'help command' into the matlab window
% HINT 2:
% use section evaluations (Ctrl+Enter) to run the code within a single
% section

%-----
% v.0.9 - 13-11-2014
% by Michael Heuer
%-----
% Last modified on 25-11-2014
% by Julian Theis
% -----

clear all; clc; close all
```

## I. Setup some global Variables which will be needed later

```
t_s = 0.01; % Sampling Time of the datasets
```

---

## II. Load the measurment data into an iddata object

The data are stored in the vector called 'data' The first row is the time, the second and third u\_1 and u\_2, and the fourth and fifth y\_1 and y\_2. Those are copied into a iddata object which can be used for the identification.

```
load d_steps.mat;
u_1 = data(:,2); u_2 = data(:,3);
y_1 = data(:,4); y_2 = data(:,5);
d_steps = iddata([y_1, y_2], [u_1, u_2], t_s);

load d_chirp_1.mat;
u_1 = data(:,2); u_2 = data(:,3);
y_1 = data(:,4); y_2 = data(:,5);
d_chirp_1 = iddata([y_1, y_2], [u_1, u_2], t_s);

load d_chirp_2.mat;
u_1 = data(:,2); u_2 = data(:,3);
y_1 = data(:,4); y_2 = data(:,5);
d_chirp_2 = iddata([y_1, y_2], [u_1, u_2], t_s);

load d_prbs_1.mat;
u_1 = data(:,2); u_2 = data(:,3);
y_1 = data(:,4); y_2 = data(:,5);
d_prbs_1 = iddata([y_1, y_2], [u_1, u_2], t_s);

load d_prbs_2.mat;
u_1 = data(:,2); u_2 = data(:,3);
y_1 = data(:,4); y_2 = data(:,5);
d_prbs_2 = iddata([y_1, y_2], [u_1, u_2], t_s);

load d_noise_1.mat;
u_1 = data(:,2); u_2 = data(:,3);
y_1 = data(:,4); y_2 = data(:,5);
d_noise_1 = iddata([y_1, y_2], [u_1, u_2], t_s);

load d_noise_2.mat;
u_1 = data(:,2); u_2 = data(:,3);
y_1 = data(:,4); y_2 = data(:,5);
d_noise_2 = iddata([y_1, y_2], [u_1, u_2], t_s);
```



## III. Open the System Identification Toolbox and performe the identification

In this step the identification should be performed using the gui. Take a look at the lab document and performe the required steps.

Store the identified system in the pattern sys\_\* Where \* is the dataset you used for the identification.

```
systemIdentification;
```

```
pause();
```



## IV. Save the identified models

```
if (sys_steps.ts ~= 0) || (sys_chirp_1.ts ~= 0) || (sys_chirp_2.ts ~= 0) || ...
    (sys_prbs_1.ts ~= 0) || (sys_prbs_2.ts ~= 0) || (sys_noise_1.ts ~= 0) || (sys_noise_2.ts ~= 0)
    error('Please convert the systems to continuouse time');
end


save models.mat sys_steps sys_chirp_1 sys_chirp_2 sys_prbs_1 sys_noise_1 sys_prbs_2
```


---

## V. Compare the models

```
% Compare Bode Plots
figure(1);
b = bodeoptions();
b.XLim = {[1,250]};
b.YLim = {[ -40 40]};
bodemag(sys_steps, sys_prbs_1, sys_noise_1, sys_prbs_2,
        sys_noise_2,b);
legend({'steps','prbs1','noise1','prbs2','noise2'},'Location','SouthWest');

% Compare Poles
figure(2);
iopzmap(sys_steps, sys_prbs_1, sys_noise_1, sys_prbs_2, sys_noise_2);
legend({'steps','prbs1','noise1','prbs2','noise2'},'Location','SouthWest');
```





*Published with MATLAB® R2019b*